

Frequently Asked Questions

- How can this product help protect my employees and the public? Covering hard, high touch surfaces like door handles, stair rails, elevator buttons, public transportation handholds with Kleen-Slate antimicrobial film places the active microbe-inhibiting silver/copper ions where the microbes are likely to be deposited. This creates a hostile environment for the microbes, reducing the number of microbes that will be alive when the next person touched the surface.
- How long does the product last before it needs to be replaced? This is highly dependent on how often it is exposed to microbes. General guidance is that the film should be replaced 1) when physical wear/tear is visible, 2) after 90 days of high traffic use such as on door handles, or 3) after 6 months of moderate uses like touch screens.
- How is Kleen-Slate film applied/installed? Kleen-Slate is a flexible tape that can be applied to any hard, clean surface. It is important to make certain the surface is clean before applying. Rub the film onto the surface to remove any bubbles that may be trapped between the Kleen-Slate film and the surface to which it is being applied and to make sure that the film has adhered to the surface well. Application of heat will cause the film to shrink-wrap slightly, wrapping around slightly curved surfaces for a good fit. However, caution must be used to not damage the Kleen-Slate film or the surface to which it is being applied.
- Is there any risk using this product? No risks have been identified at this time. The active ingredient in Kleen-Slate is used in medical devices, surgical masks, and other highly critical use cases for years with no known adverse effects.
- If it is used on tables, can food be eaten after coming in contact with the product? Yes. The active ingredient in Kleen-Slate is rated for use on food-contact surfaces.
- How do you clean the product? Does cleaning the product impact overall effectiveness? Regular cleaning will not impede the effectiveness of Kleen-Slate. Kleen-Slate is not intended to take the place of traditional cleaning programs but is intended to help reduce the microbial activity on surfaces between cleanings.

Antimicrobial Film





Touch Screen To Orde

